

Side By Innovations Mirror Bar Installation

1. Remove the screws and separate both clamps as shown on right view.
2. Have someone hold the mirror bar assembly in position. Re-assemble the clamp halves at each end of the mirror bar so they wrap around the roll bar as shown (Left view). Tighten the screws.

NOTE: Be careful to line up the screw holes so the screws start in straight! They will start in easily if they are straight. Cross threading will damage the clamp.

3. Adjust each mirror position by loosening the adjustment knob on the bottom back side of the mirror. Position the mirror and re-tighten the knob. With the knob loose, the mirrors will rotate up and down and side to side.

